Help Guide 10a

How do I completely remove the FilesThruTheAir™ WiFi Sensor Software from my PC?









What is this?

This Help Guide refers to the FilesThruTheAir™ WiFi Sensor Software.

How do I completely remove the FilesThruTheAir™ WiFi Sensor Software from my PC?

1. Uninstall the WiFi Sensor Software.

Windows XP/Vista: use Control Panel | Add or Remove Programs

Window 7: use Control Panel | Programs

Windows 8 & 10: search Programs and Features.

Locate the WiFi Sensor Software in the list and select Remove or Uninstall.

- 2. Completely remove the folder **Program Files\Wifi Sensor Software**. This might be **Program Files (x86)\Wifi Sensor Software** on some operating systems.
- 3. Completely remove the folder My Documents\WiFi Sensor Software. This might be **Documents\WiFi Sensor Software** on some operating systems.
- 4. Delete the file My Documents\config.wft. This might be **Documents\config.wft** on some operating systems.

The software and any related data is completely removed.